



- Suspend Lane 1 S/B
- Widen F/Way 1.5m Into Carriageway
- Install New Cycle Lane In Carriageway - 1.5m
- Barrier May Need Removed

- No Change To Taxi Bay
- Suspend Parking Bays
- Widen F/Way By 1m Into Parking Bay Area
- Install New Cycle Lane Within Parking Area (1m Parking Area & 0.5m Carriageway)

- Suspend Bus Lane
- Loading Bay Stays But Is Moved Out Into Carriageway By 1m
- Widen F/Way By 1m
- No Cycle Lane Can Be Accommodated Through This Section

1. Suspend All Parking Bays
- Widen F/Way By 1m
- Excluding 2no Refuse Bins
- Install New Cycle lane 1.5m Outside Widened F/Way Exc Refuse Bin Location

2. Suspend Bus Stop and Relocate Outside no23
- Reduce N/B to 1no Lane(remove left lane)
- Widen Footway By 1.5m
- Install New Cycle Lane 1.5m

Reduce Loading Bay To Half Length

Widen F/Way By 1m. New Cycle Lane Shown Outside F/Way Widening Excluding Loading Bay

Close Bus Stop Furthest South and reduce to 1no Bus Stop

Widen F/Way By 1m

New Cycle Lane - 1.5m

Close Loading Bay And Relocate In Tarvit Street

Widen Footway by 1.5m either side to widen crossing points as with Lochrin Place

Close Loading Bay And Relocate In Lochrin Place

New Cycle Lane - 1.5m from Kerbline

Close Left Turn Lane F/Way Widened By 1.5m

Cycle Lane On Outside of Widened F/Way

Relocate Loading Bay into Bus Lane - Widen F/Way By Loading Bay Width

No Cycle Lane

Suspend Bus Lane

Widen F/Way By Half Bus Lane

Cycle Lane Remaining Width

2no Loading Bays Remain Open

CEC

Spaces For People
Tollcross
DWG - 001a

CONTRAFLOW LTD.

CONTRAFLOW LTD
1 WARDPARK ROAD
WARDPARK SOUTH INDUSTRIAL ESTATE
CUMBERNAULD G67 3EX
Tel. 01236 862 400
Fax. 01236 862 402

Date: July20	Scale: N.T.S	Drawn by: M.Clusker
DRG. NO.Spaces For People - DWG - 001		